

Graphene Auto-Kirigami: Forming 3D Structures Through Atomic Force Cutting



Jacob Goell ('2025)¹, Li Yuan¹, Robert W. Carpick¹



¹University of Pennsylvania, Department of Mechanical Engineering and Applied Mechanics



Introduction and Motivation

2D Materials

- 2D materials are structures with a thickness of a singular atom.
- These materials have remarkable mechanical, thermal, and electrical properties.




"Stacking 2D Materials," Churchill Lab, <http://churchill-lab.com/research>

"Schematic Illustration of a Graphene Transistor Prototype," Phys.org, February 19, 2013, <https://phys.org/news/2013-02-graphene-transistor-principle.html>

- Graphene has an extremely high stiffness and is highly conductive.
- Possible applications in electrical components, optics, solar cells, etc.

Auto-Kirigami

- Indentation or cutting can cause graphene to form 3D structures spontaneously; called Auto-Kirigami
- Controlling this phenomena could enable new nano-manufacturing methods for graphene components.





Annett, J., Cross, G. Self-assembly of graphene ribbons by spontaneous self-tearing and peeling from a substrate. *Nature* 535, 271–275 (2016). <https://doi.org/10.1038/nature18304>

However, many of the parameters affecting Auto-Kirigami are not fully understood. Thus, a systematic exploration of these parameters and their effects is needed to harness Auto-Kirigami for future applications.

We seek to cut graphene while varying humidity and observe frictional changes as well as changes in Auto-Kirigami. Findings will allow us to further understand the phenomena and move us one step closer to manipulating and controlling the process.

Creating Graphene


- Graphite flakes are exfoliated with scotch tape and then are transferred to a clean SiO₂ substrate and observed with optical microscopy.



Freire Soler, Victor Manuel. (2014). Fabrication and Characterization of Macroscopic Graphene Layers on Metallic Substrates.



Atomic Force Microscopy

- Atomic Force Microscopy, or AFM, is how we image and cut samples
- In tapping mode, a tipped cantilever repeatedly taps the surface of the material, generating 3D plots of various measurements.





Cutting Graphene

- In contact mode, the cantilever drags the tip along the surface of a material, generating friction plots simultaneously,



Varying Humidity


- Humidity is varied by feeding N₂ and Water Vapor into a humidity cell and stabilizing the RH at a specific level.



Results



Determining Layer Number

- We can use Raman Spectroscopy and take the ratio of Graphene's 2D and G peaks to determine the layer number.
 - I_{2D} / I_G ratios of ~2 confirm that the sample is a monolayer.




Friction Measurements

- Fracture will begin at defect points along the surface of the material, such as a wrinkle.



- The highlighted portion of the friction measurement corresponds to where a wrinkle intersected with the cutting line.


Friction Progression



- We can observe how the friction changes over time as we increase the force applied by our AFM Tip.
- We can see fracture happens at similar forces but takes different paths to reach there.

Auto-Kirigami

- We have observed similar final tear and twist angle among single rip Auto-Kirigami and is likely a result of the lattice orientation of the graphene.
- This cut was made at low Relative Humidity (RH) (1-2%).



Conclusions

- We have developed a consistent method to cut graphene as well as record frictional data to obtain data at the point of fracture.
- We have identified points of interest in Auto-Kirigami which will give direction for structuring experiments in the future.
- Not enough data has been taken, and so more cuts are needed.

Future Research

- Create more cuts and gather data at all levels of humidity, especially those in the 75-85% RH range.
- Further investigate similar angle tears at low humidity.
- Use Raman Spectroscopy to identify twist angles amongst folded layers

Acknowledgements



This work was made possible through the Center for Undergraduate Research's PURM program at the University of Pennsylvania.



This work was carried out in part at the Singh Center for Nanotechnology, part of the National Nanotechnology Coordinated Infrastructure Program, which is supported by the National Science Foundation grant NNCI-2025608.